

1 Take advantage today of the fixing solution of tomorrow | FlexxMax® www.flexxmax.com




Installation:

Attach the FlexxMax-base by using the rightmounting materials. Mounting onto curved (A) or flat surfaces (B).

Smartband



Wall mounting




Place the ratchet-bar from the top into the FlexxMax-base and push it downwards.

Put in the sign, lock the Flexxmax by pushing the ratchet-bar downwards until the sign is fixed.

To remove or change the locked sign, just push the ratchet-bar slightly to the back (c) and move it upwards (d) at the same time.


Flexx-SmartBand, Buckle and Clamping Tool




Insert band into closed side of the buckle.




Pull band through backcross of Flexx-Base.



Wrap band around support and insert into opposite end of Buckle.



Use tightening tool to tighten band.



Use cutter blade on tool to remove excess band.